

## PAC OEM-1 CABLE APPLICATION GUIDE Revised 3-4-02

### Cables to replace factory amplifier or adding an aftermarket amplifier

("C" cable and AMP-RCA required with OEM-1)

				"C" Cables
MAKE	MODEL	MODEL	YEAR	PART #
BUICK	LE SABRE Bose not Concert Sound	PARK AVENUE Bose not Concert Sound	1995-2000	ADD-GM-32
	LE SABRE	PARKAVENUE	1988-94	ADD-GM21
	RIVIERA		1996-98	ADD-GM32
	RIVIERA		1990-95	ADD-GM21
	ROADMASTER		1995-96	ADD-GM21
CADILLAC	ROADMASTER		1991-94	ADD-GM21
	COUPE DEVILLE		1988-93	ADD-GM21
	COUPE DEVILLE		1985-87	ADD-GM12
	DEVILLE		1994-98	ADD-GM32
	ELDORADO		1992-99	ADD-GM32
	ELDORADO		1988-91	ADD-GM21
	ELDORADO		1983-87	ADD-GM12
	ESCALADE		1999-2002	ADD-GM21A
	FLEETWOOD		1988-93	ADD-GM21
	FLEETWOOD		1985-87	ADD-GM12
	SEVILLE		1992-97	ADD-GM32
	SEVILLE		1988-91	ADD-GM21
SEVILLE		1984-87	ADD-GM12	
CHEVROLET	CAMARO		1998-2002	ADD-GM21C
	CAMARO		1990-97	ADD-GM21
	CAMARO		1986-89	ADD-GM12
	CAPRICE		1991-96	ADD-GM21
	CORVETTE		1997-2002	ADD-VET1
	CORVETTE		1990-96	ADD-GM21
	CORVETTE		1984-89	ADD-GM12
	LUMINA		1990-98	ADD-GM21
	SUBURBAN,TAHOE, BLAZER	2001-2002 TAHOE non Bose, use ADD-GM21C	1998-2002	ADD-GM21A
CHRYSLER	CHRYSLER INFINITY SYSTEMS		All-2001	ADD-CHR
GMC	SUBURBAN , YUKON, JIMMY, ENVOY, DENALI		1998-2002	ADD-GM21A
OLDSMOBILE	AURORA		1995-2000	ADD-GM32
	BRAVADA		1998-2001	ADD-GM32A
	INTRIGUE		1998-2001	ADD-GM32
	NINETY EIGHT		1994-96	ADD-GM32
	NINETY EIGHT		1986-93	ADD-GM12
	TORONADO		1988-93	ADD-GM21
PONTIAC	BONNEVILLE		1999	ADD-GM21C
	BONNEVILLE		1992-98	ADD-GM21
	BONNEVILLE		1985-91	ADD-GM12
	FIREBIRD		1998-2002	ADD-GM21C
	FIREBIRD		1990-97	ADD-GM21
	FIREBIRD		1986-89	ADD-GM12
FORD / LM	GRAND PRIX		1999-2001	ADD-GM21B
	EXPLORER, CROWN VICTORIA, RANGER, MOUNTAINEER,CONTINENTAL		1998-2002	ADD-FRD3*****
	MUSTANG MACH SYSTEM		1994-1999	ADD-FRD1
	ALL OTHER FORD - JBL & MACH SYSTEMS		1996-98	ADD-FRD2
	ALL FORD JBL SYSTEMS		1989-95	ADD-FRD1
	NAVIGATOR, EXPEDITION, EXCURSION		1999-2002	ADD-FRD3*****
	FORD LUX RADIO, STEREO'S WITH NO ANTENNA PLUGGED INTO IT			N/A
ACURA/HONDA	HONDA/ACURA/BOSE		1986-97	ADD-HON
NISSAN	ALL NISSAN WITH BOSE SYSTEM		1989-94	ADD-NIS1
	ALL NISSAN WITH BOSE SYSTEM		1995-2002	ADD-NIS2
MAZDA	MAZDA BOSE SYSTEMS (except Millenia)		ALL	ADD-MAZ
TOYOTA	TOYOTA VEHICLES		1992-99	ADD-TOY
	LEXUS AND AVALON		ALL	ADD-UNV
VOLKSWAGEN	VOLKSWAGEN BOSE		1987-99	ADD-VLK
Universal low level input harness for cars not listed above.				ADD-UNV

**This cable is also required for when using "C" cables with OEM-1**

AMP-RCA

\* OEM-1 is not required, this harness plugs directly into stereo "A" cable.

\*\*\* OEM-1 Not required. Requires SNI-35 if factory subwoofer is used.

\*\*\*\*\*Requires model TR-4 to allow trigger on for aftermarket amplifiers to operate.

## Cables to connect aftermarket stereos to factory amplifiers.

("A" and "B" cables required with OEM-1)

				"B" Cables
MAKE	MODEL	MODEL	YEAR	Part #
<b>BUICK</b>	LE SABRE Bose not Concert Sound	PARK AVENUE Bose not Concert Sound	1995-2000	AMP-GM32
	LE SABRE	PARK AVENUE	1988-94	AMP-GM21
	RIVIERA		1996-98	AMP-GM32
	RIVIERA		1990-95	AMP-GM21
	ROADMASTER		1995-96	AMP-GM21
<b>CADILLAC</b>	ROADMASTER		1991-94	AMP-GM21
	COUPE DEVILLE		1988-93	AMP-GM21
	COUPE DEVILLE		1985-87	AMP-GM12
	DEVILLE		1994-98	AMP-GM32
	ELDORADO		1992-99	AMP-GM32
	ELDORADO		1988-91	AMP-GM21
	ELDORADO		1983-87	AMP-GM12
	ESCALADE		1999-2002	AMP-GM21A
	FLEETWOOD		1988-93	AMP-GM21
	FLEETWOOD		1985-87	AMP-GM12
	SEVILLE		1992-97	AMP-GM32
	SEVILLE		1988-91	AMP-GM21
<b>CHEVROLET</b>	SEVILLE		1984-87	AMP-GM12
	CAMARO		1998-2002	AMP-GM21D *
	CAMARO		1990-97	AMP-GM21
	CAMARO		1986-89	AMP-GM12
	CAPRICE		1991-96	AMP-GM21
	CORVETTE		1997-2002	AMP-VET1
	CORVETTE		1990-96	AMP-GM21
	CORVETTE		1984-89	AMP-GM12
	LUMINA		1990-98	AMP-GM21
	SUBURBAN,TAHOE, BLAZER	2001-2002 TAHOE non Bose use AMP-GM21D*	1998-2002	AMP-GM21A
	CHRYSLER	CHRYSLER INFINITY SYSTEMS	ALL-2001	AMP-CHR
<b>GMC</b>	SUBURBAN , YUKON, JIMMY, ENVOY, DENALI	1998-2002	AMP-GM21A	
<b>OLDSMOBILE</b>	AURORA		1995-2000	AMP-GM32
	BRAVADA		1998-2001	AMP-GM32A
	INTRIGUE		1998-2001	AMP-GM32
	NINETY EIGHT		1994-96	AMP-GM32
	NINETY EIGHT		1986-93	AMP-GM12
<b>PONTIAC</b>	TORONADO		1988-93	AMP-GM21
	BONNEVILLE		1999	AMP-GM21C
	BONNEVILLE		1992-98	AMP-GM21
	BONNEVILLE		1985-91	AMP-GM12
	FIREBIRD		1998-2002	AMP-GM21D *
	FIREBIRD		1990-97	AMP-GM21
	FIREBIRD		1986-89	AMP-GM12
<b>FORD / LM</b>	GRAND PRIX		1999-2001	AMP-GM21B
	EXPLORER, CROWN VICTORIA, RANGER, MOUNTAINEER, CONTINENTAL		1998-2002	AMP-FRD3***
	MUSTANG MACH SYSTEM		1994-1999	AMP-FRD1
	ALL OTHER FORD - JBL & MACH SYSTEMS		1996-98	AMP-FRD2
	ALL FORD JBL SYSTEMS		1989-95	AMP-FRD1
	NAVIGATOR, EXPEDITION, EXCURSION		1999-2002	AMP-FRD3***
	FORD LUX RADIO-NO ANTENNA PLUGGED INTO HEAD			N/A
<b>ACURA/ HONDA</b>	HONDA/ACURA/BOSE		1986-97	AMP-HON
<b>MAZDA</b>	MAZDA BOSE SYSTEMS (except Millenia)		ALL	AMP-MAZ
<b>NISSAN</b>	ALL NISSAN WITH BOSE SYSTEM		1989-94	AMP-NIS1
	ALL NISSAN WITH BOSE SYSTEM		1995-2002	AMP-NIS2
<b>TOYOTA</b>	TOYOTA VEHICLES EXCEPT LEXUS		1992-99	AMP-TOY
	LEXUS		ALL	AMP-UNV
<b>VOLKSWAGEN</b>	VOLKSWAGEN BOSE		1987-99	AMP-VLK
Universal harness for cars not listed above				AMP-UNV
<b>Cables to connect aftermarket stereos to OEM-1</b>				<b>"A" Cables</b>
	ALPINE			ALP16
	AUDIOVOX			AUD14
	BLAUPUNKT			BLA16
	CLARION			CLA16
	CLARION 1999 & newer Models	1999 & 2000 Models		CLA16A
	ECLIPSE			ECL16
	ECLIPSE 1999 & newer Models	1999 & 2000 Models		ECL16A
	JVC			JVC16
	KENWOOD			KEN16
	PANASONIC			PAN16
	PIONEER	12 PIN PLUG		PIO12
	PIONEER	14 PIN PLUG		PIO14
	PIONEER	16 PIN PLUG		PIO 16
	ROCKFORD	2000 Models		ROC16
	SANYO			SAN12
	SONY			SON16
Universal harness for aftermarket stereos with speaker level outputs not listed above				RAD-UNV
Universal harness for aftermarket stereos with only pre-amp level outputs				RAD-RCA

Pacific Accessory Corporation - 1502 S. Santa Fe Street, Santa Ana, CA 92705

www.go2pac.com

Voice: 714-835-3133 Fax: 714 835-3233

techsupport@go2pac.com