



OEM-1

Interfacing Information Bulletin **Number 6**

July 23,1998

Vehicles: 1990-1996 Chevrolet Corvette with Bose system

Product: AMP-GM21, ADD-GM21

Symptom: The GM21 cables don't fit the connectors behind the factory head. On this vehicle it is a control unit only.

(note, there is no antenna lead into the head)

The receiver and preamp are located behind the right seat, there you can access the GM 21 pin connector.

Correction: When **replacing the factory head unit**, locate the receiver module behind the right seat under the storage compartment. Disconnect the 21 pin connector and plug in the AMP-GM21 harness and the OEM-1 interface box. Extend the new head unit cable from the dash to this area and plug into the OEM-1. Note that the antenna lead will also have to be extended from the rear location to the dash.

When **adding amplifiers to the factory system** install the ADD-GM21 harness, the OEM-1 and AMP-RCA at this rear location.